

How to refill Samsung MLT-D105L MLTD105L ML-1915, ML-2525, ML-2525W, ML-2580n, SCX-4600, SCX-4623F, SCX-4623FW, SF-650, SF-650P ,DELL 1130 1130n 1133 1135n

Take the cartridges out of printer, using the paper town to cover the drum (green parts) of the cartridges. This will help to protect the drum to explode to the light.



Place the cartridge in horizontal position with the side cover holding the chips facing you. Take the blade and cut the head of the plastic rivet. Be careful with the movement, keeping the blade from slipping and cutting yourself, there 4 of these on the cartridge.



After cut all 4 plastic rivet, using the small screwdriver, slightly separate the cover.



Using the small flier, or a knife to cut (break) a section on the plastics cover so we insert the small flat head screwdriver to remove the plug easy later. This is the optional step you do not need to do it.



Remove the fill plug and Empty the hopper/cartridge and clean thoroughly by using a vacuum.. This step is very important; better cleaning of the cartridge and not mixing previous toner with new toner, the better quality printing result.

After cleaning the cartridges Fill the toner hopper with the proper amount of toner for use in Samsung D105 cartridges, and tightly close with the plastic



Replace the chip with a new one and sliding it in place.

NOTE: Under normal working conditions the printer will eventually call for toner cartridge replacement. The printer will need to read a new chip to reset the counters and to print. For this reason, it is recommended that